


Setting up your new phone.





We offer Premium Product Care

Did you know that the average Samsung repair cost for a damaged new device is approximately \$400.

A smartphone is an expensive investment, most of us rely on them in our everyday lives. So what do you do if they break or get stolen?

Premium Product Care is the answer for you:

\$15 per month on top of your phone plan.

No excess.

1 claim per 24 month mobile contract.

Receive a replacement device within 24 business hours.

For further information call 1300 010102 option 1 AU or 0800 828123 NZ or email telco.au@ubteam.com

Welcome to your new Smartphone

Supplied by UBT and powered
by Streamline3 for Android.



Scan this QR Code
for Video Tutorial:
"Streamline3 Install Guide"




For further set up instructions
(including using Smart Switch
setting up email, Whatsapp etc.)
check out our handy guide.






Step 1. Power on your device.


The power button is usually the smaller button located on either the left or right of your device, near the top. Please consult your device's 'quick start' guide for more info.



Step 2. Getting started.




Tap 'Start' on the welcome screen and agree to the EULA, privacy policy and (optional) the sending of diagnostic data.



Step 3. Important Update

Samsung devices only


If at any stage through the process you are presented with the options to copy apps and data or set up using another device:




Please select the “Set up Manually” or “Skip” options. Smart Switch cannot be completed until AFTER your Streamline3 installation.



Step 4. Connect to Wi-Fi.




Connect to Wi-Fi by tapping your network name, then entering your password.



Your device may prompt to perform a restart. If prompted please tap restart to allow this to be completed, otherwise continue to Step 5.




Step 5.



When the device displays the screen shown, tap 'Set up later in settings.'


Continued...



Your device will now start the set up procedure and will display the above screens for approximately 3-5 minutes.




Step 6.



At this screen, tap 'Next'.

Step 7.





Step 8. This device isn't private.

Note:


Neither the Streamline3 app, nor any Streamline3 or UBT personnel, have any access at all to user's files, media, emails, messages, phone calls or call logs, usage activity, contacts, camera access or device location of Streamline3 devices. Streamline3 does collect some technical data (such as device IMEI, network ID and SIM information) for debugging, troubleshooting, diagnostic and analytical purposes.

You can view the privacy policy here:

<https://www.ubtsupport.com/legal/privacy.php>

or please contact your local UBT Telco office for more information if you have any questions.


Step 9. Google Services.




Review and agree to Google services permissions. Once reviewed, tap 'Accept'.



Step 10. Activate Streamline3.




Tick the box and tap 'Activate'. Your device will then show a screen similar to the right hand screen above for approximately 1-2 minutes.





Step 11. Set screen lock method.




Your device will now prompt you to set an unlock method, choose your preferred method and follow the on-screen instructions.

Step 12. Activate Knox.



Activate Knox (Samsung's security system) by tapping 'Next', then 'Agree' in the screen after that.

Congratulations, you should now be ready to go!



 **Streamline**³

 **UBT**
TECHNOLOGY